




Basic Guide of Flash Scanner

FireCR flash

Training Contents



 FireCR Flash Scanner Installation

 Imaging Plate

 How Flash scanner works

 Common Issues.

❖ Flash scanner installation

1. Take out a Flash Scanner and accessories in the box.

- Components

Item	Quantity
FireCR Flash Scanner	1
Power Cord	1
Dust Cover	1
USB 2.0 Interface Cable	1
Cassette 35 x 42 cm	1
Cassette 24 x 30 cm	1
Extractor	1
Dongle (Option)	1
Speed Plate (Option)	1

2. Check all components that are in the box.

3. Take out flash scanner.

4. The flash scanner must be placed on the flat desk with at least 50 cm free space on the front side.

Free space of 20 cm back side.

4. Connect power cord and USB cable on the back of flash scanner.

- Connection



Note: You must connect USB cable to USB port 2.0 of PC.
3DISC doesn't officially support the USB 3.0.

5. Connect a dongle to PC. (Q dongle)

6. Download and install Quantor software. Please refer to the below website


<http://www.3discimaging.com/installation-files/>

7. Quantor software installation


- Log on a PC with an administrator account.
- Connect the Q USB dongle to a USB port.
- Launch software file, “QuantorMed 2.x.x Setup.exe”
- Click the “Next” button.



- Choose all components and click the “Next” button.



- Choose your language and click “Next” button.



- Choose FireCR model and click the “Next” button.






Figure 2-4 FireCR Model Selection Dialog Box


- Choose the reader position and click the “Next” button.




- Choose the destination folder and click the “Install” button.



- Installation status of the FireCR USB driver will be displayed.



- Installation is successful..
- Click "Finish" to finish the installation.



- The Windows Security Dialog Box pops up after installation, click [Allow access].




9. Run the Quantor+ as administrator rights.
10. It is automatically downloaded when it starts up

❖ Imaging Plate

- The function of **“Imaging Plate”**

- 1) Imaging plate is a flexible plate of 1mm or less thickness coated with fine photostimulable phosphorus crystal.
- 2) Temporarily stores the X-ray energy image in portion to the X-ray intensity it receives.
- 3) The stored energy is released as visible light when a laser in the CR Reader scans the IP.
This phenomenon is generally called “photostimulable luminescence” (PSL)
- 4) The image on the imaging plate is erased when exposing excessive light.


- the phenomenon of fading (loss of the recorded signal) occurs, which is disadvantageous for image acquisition.



[Description of CR system workflow]

❖ Basic configuration of CR (=Computed Radiography) system

1. X-ray image is stored on IP.
2. It is scanned with a 650 nanometer (nm) laser beam to produce PSL radiation corresponding to the absorbed x-ray energy.
3. The luminescence radiation stimulated by laser scanning is collected through a light guide into photomultiplier tube(PMT) which converts it into electric signals.
4. The signal output from the detector is an analog signal and the output from the analog to digital convertor is time-series digital signal that is being processed.
5. The residual image is erased when exposing excessive light.



❖ Flash Scanner Youtube Vedio

<https://www.youtube.com/user/3DISCimaging>

❖ 3DISC FireCR Scanner Specification



▪ FireCR Plus Scanner


- High throughput – up to **70** plates per hour.
- Resolution, **100** micron meter [um]
- Ultra light, **30 kg**
- Accomodates two standard cassettes sizes, **17 x 14 [Inch], 10 x 12 [Inch]**
- Wall mount option for minimum space occupancy.
- One step integrated scanning and erasing



▪ FireCR Flash Scanner

- High throughput – up to **70** plates per hour.
- Resolution, **100** micron meter [um]
- Ultra light, **19.5 kg**
- Accomodates three standard cassette sizes. **35 x 43[cm], 24 x30[cm], 18 x 24[cm]**
- Wall mount option for minimum space occupancy.
- One step integrated scanning and erasing.

❖ Understanding FireCR; Flash Block Diagram




❖ Understanding FireCR Flash;

Flash scanner largely consists of three assemblies




FiberModuleAssembly

It collects the light released from IP, and then light is transformed to analog signal




LaserOpticsModuleAssy

It manages image processing, laser control and power distribution.



BottomModuleAssembly

It manages moving an IP



❖ Basic Function of Main board (1)

- It control all the peripheral to be allowed to work as predefined process.

• ADC board


- Analog data is sent to ADC board from PMT through optic fiber.
- Every line converts analog signal to Digital signal

• Step motor drive chip

- It controls step motor speed, force etc

• Reset switch

- Reboot the scanner



Micro SD card has their own unique data, so SD card is not exchangeable each other. Must program it before installing it.

• Flat cable connector

- All the signals are sent to main board through flat cable

Flash scanner supports both ethernet connection an USB connection.

• MCU & FPGA

- The brain that controls the Hardware.
- It is a semiconductor chip to control the function that can be allowed to acquire the images.
- System parameters, Firmware info etc are loaded to MCU when booted up

❖ Basic Function of Main board (2)





Figure 1: MCU Structure

❖ Basic Function of Main board (3)




ADC Analog to Digital Conversion

The role of the Analog-To-Digital Conversion (A/D) is to convert analog voltage values to digital values. Digital values mean Binary number of 16 bits. The more bits the binary number has, the higher the resolution, the better the accuracy.



65536 levels

It displays the image more precisely with 65536 levels



❖ Common Issue with Main Board (1)

Losing USB connection or stopped reading the image data during midscan.

1) Lack of power from USB port on PC. Adding a powered USB hub can solve this issue.

The latest main board has applied circuit medication to prevent USB connection issue from shortage of power from PC USB port.

2) Damaged USB chipset on the main board. Main board need to be replaced.

Booting issue

1) Square mirror is spinning, front led is off, and red laser is off while booted up. Firmware, Sysinfo data are not loaded to MCU while booted up.

2) Poor micro SD card connection can cause booting issue. In this case, reconnecting a micro SD card can solve this issue. If it does not help, it means that bootloader file is corrupt in the MCU chip, so it can not download data from micro SD card.

3) Either main board replacement or installing data to MCU using ST-link can solve the issue.

One horizontal line in the middle of image

1) Most cases of one horizontal line is caused by broken tag. Bad writing speed on micro SD card and bad main board can cause broken tag.

2) Tag is information on per each scanning line. Tag contains information triggered by PSD such as scanning start, scanning end, RPM or the number of line etc.

3) Tag information is found in raw image only acquired by SDKContainer.

❖ Common Issue with Main Board (2)

Stage moves to limit position when booted up

- 1) Stage moves to home position when booted up, but in contrast, it moves to limit position when booted up.
- 2) Poor flat cable connection can happen. Reconnecting a Flat cable can solve this issue.

The image with horizontal band


- 1) If it has an issue with the image with horizontal bands, either an ADC board or a PMT can cause this issue.
 - 2) The purpose of ADC board is to convert an analog signal into digital signal. Wrong ADC can cause horizontal band across the image.
 - 3) There are two types of PMT. One with Mu metal. The other without Mu Metal. The purpose of Mu metal minimizes bad effect on magnetic field.
-

❖ Main board Revision History


Main board version	Released date	Improvement	Compatibility
V1.2		Initial board	FireCR flash AA
V1.2B	2015.May.4	1) Circuit change to prevent "Losing USB connection." 2) VBUS register change: 10kΩ → 1kΩ to prevent "Stop in the middle of scan"	FireCR flash AA to AC
V1.3	2015.Nov.18	Add USB protection circuit to prevent "Losing USB connection"	FireCR flash AA to AC
v.14	2016.May.23	Add buffer around reset switch to delete noise.	FireCR flash AA to AC

❖ Basic Function of BLDC Board

- It maintains the square mirror rotate at same speed.
- Predefined RPM 1800 is controlled by dip switch.



- **Dip switch**
 - Dip switch is switch to get BLDC motor rotate at defined speed.
 - It must set "0101".



현재 상태 = 0011

				SW1	SW2	SW3	SW4
				ON/OFF	Project		Motor Type
ON	FireCR+	old motor		0	0	0	0
		new motor		0	0	0	1
	Dental	old motor		0	0	1	0
		new motor		0	0	1	1
	Flash	old motor		0	1	0	0
		new motor		0	1	0	1

스위치 1 번은 차후에 변경 예정입니다.

옵티스 모듈 번호 OYYMMVV-XXXXX 에서 VV(=Version)가 '07'이상인 모듈은 신형모터 적용 되었음

❖ Common Issue with BLDC Board

Unstable RPM

- 1) Unstable RPM can cause bad image quality.
- 2) Either bad BLDC motor or bad BLDC board causes unstable RPM.

If you can hear noisy operation sound from BLDC motor, we need to replace a laser steering assembly. If not, a BLDC board need to be replaced.

No power

- 1) It never turns on the power.

Short circuit between power board and BLDC board can cause no power issue. It turns on with BLDC cable off. In this case, BLDC board need to be replaced.

❖ Basic Function of Laser Steering Assembly (1)

- The purpose of laser steering assembly is to stimulate the image plate, and then release the blue light.
- Laser steering assembly consists of three parts. Laser module, Square mirror and F-theta lens.

• Square mirror


- It rotates at 1800 [RPM]
- BLDC board maintains rotating a BLCD motor at the same speed. It can be allowed to scan the IP.
- Do not touch BLDC mirror, it can affect Square mirror alignment. Bad alignment can make lines across the image.

• Laser module

- It is a source of red laser.
- Transmit $650 \text{ [nm]} \pm \delta$ wavelength Red light
- Laser power is within $50 \pm 2\text{mW}$. Laser power is weak, PSD can not read red laser.
- Laser spot size is less than $70\mu\text{m}$ HD mode resolution is $100[\mu\text{m}]$, so we must manage beam size less than $100 [\mu\text{m}]$.

• F-theta lens


- It can have a circular plane. It can affect image quality. F-theta lens has been implemented to acquire better image quality.
- A F-theta lens is provided for focusing a laser beam across the IP.




❖ Basic function of Laser Steering Assembly (2)

Square mirror

Square mirror has four mirrors. Each mirror create each line.





Well aligned mirrors



The second mirror and fourth mirror are out of alignment.

F-theta Lens



❖ Common Issue with Laser Steering Assembly

Auto align issue because of either dim laser or no laser

- 1) Degraded diode can cause RPM issue. PSD can not read dim laser.
- 2) Suspect that overcurrent can cause damaging a diode or main board does not supply enough power to a diode. Before replacing laser steering assembly, we'd better measure power on the main board.
- 3) Depending on test result, a laser steering assembly or a main board need to be replaced.

Horizontal lines across the image

- 1) Regular horizontal lines have appeared across the image.
- 2) Bad alignment on the square mirror can cause regular line across the image.
- 3) We need to check the image with horizontal lines in the factory software named SDKContainer because line removal function has been applied to the image acquired in the Quantor+.

Bad RPM

- 1) RPM value is out of tolerance. Bad RPM value is mostly caused by BLDC board, but if you hear noisy sound from BLDC motor, we need to replace a laser steering assembly.

Blurry image


- 1) If the image acquired still become blurry even though best beam find and recalibration have been done properly, there is possibility to be caused by red laser being out of focus or red laser being dim.
-

❖ Laser Steering Assembly Revision History

Laser Steering Assembly version	Released date	Improvement	Compatibility
	2015.Feb.9	Add Teflon washer	Compatible FireCR flash AA to AC
	2015.Oct.20	Improve degraded diode issue caused by overcurrent.	Compatible FireCR flash AA to AC

❖ The Basic Function of Aligner Motor

- The purpose of aligner motor is to move up and down the laser steering assembly during auto align process.
- There are two aligner motor to put laser steering assembly being tilted, up and down.



- **EllipseDisk type motor**

- No mechanical limit.
- The combination of spring force, aligner motor angle and surface roughness affect the aligner motor performance.
- Low cost

❖ Common Issue with Aligner Motor

Auto align failure


1) Auto align fails because of aligner motor does not work. In this case the faulty aligner motor need to be replaced

❖ Basic Function of Driver Board

- The purpose of driver board is to interface between peripheral and main board.
- Amplify PSD signal, and then convert analog signal into position data.
- Drive Eraser unit.
- Supply high voltage to PMT during scan only.

- **High voltage generator**

- Provide power to PMT during scan only.



❖ Common Issue with Driver Board

White image

- 1) The image acquired become white.
- 2) Damaged HVPS does not provide power to PMT, and then it gets the PMT not turned on during scanning.

Auto align failure because of no PSD values

- 1) Red laser is bright enough, also hitting PSD, but if PSD values are abnormal, it means that PSD data is not processed in the driver board.
-

❖ Driver Board Revision History

Driver board version	Released date	Improvement	Compatibility
V1.2		Initial board	Compatible with FireCR flash AA only
V1.2 + PSD MP driver		Add PSD MP driver to be compatible with new PSD MP.	Compatible with FireCR flash AB only
V2.0B		PSD MP driver is integrated.	Compatible with FireCR flash AC only
V2.0F	2015.Oct.26	Silk position and size change	Compatible with FireCR flash AC only
V2.1	2016.Apr.11	Circuit improvement to prevent “White image”	Compatible with FireCR flash AC only


❖ Basic Function of PMT (Photo Multiplier Tube)

- PMT is a sensor to detect the amount of light.
- High light sensitivity – It can detect the signal even though using less light.

- Path

: Image plate → Light → Fiber Bundle → Photocathode → Electron multiplier → Anode

- 1) Photocathode: Emit photoelectron by photoelectric effect when receiving above specific frequency.
- 2) Electron multiplier (Dynode) : Amplify electrons by the process of secondary emission. This amplifies signal.
- 3) Anode: It converts light into the electric signal.



❖ Common Issue with PMT

White image

- 1) PMT is a sensor to read the light.
- 2) If The image become white even though HVPS provides power to PMT, PMT should be defective.

Vertical band or horizontal band


- 1) Vertical bands have appeared when they installed a brand new scanner at clinic or move the scanner from one place to another.
 - 2) According to RnD's research, Electromagnetic field change according to scanner location change causes the mismatch between calibration file and current fiber bundle profile image, and then it leads to the image with vertical band. Mu Metal minimizes electromagnetic field affected to the image quality.
-

❖ PMT Revision History

PMT version	Released date	Improvement	Compatibility
	2015.Nov.18	Add Mu Metal to minimize magnetic field	Compatible with FireCR flash AA to AC

❖ Basic Function of PSD (Position Sensitive Detector) (1)


- PSD means **P**osition **S**ensitive **D**etector.
- It measures a position of a light spot on a sensor surface.
- It converts an light spot into continuous position data.
- It can determine scan start position and scan end position



❖ Basic Function of PSD (Position Sensitive Detector) (2)



Actual PSD

PSD reading range: -14384 ~ 11384



Ideal PSD

PSD reading range: -16384 ~ 16384



- The purpose of PSD calibrator is to optimize the scale of PSD reading range to prevent premature PSD saturation.
- Higher negative PSD value, the closer fiber bundle, the better image quality

❖ Common Issue with PSD

Auto align failure


- 1) If either PSD can not read the red laser, there is a possibility to be caused by damaged PSD.
- 2) It rarely happens.

Jagged image

- 1) Both PSDs determine scanning starting position and scanning ending position.
 - 2) Scanning starting position and scanning ending position per each line can be varied by damaged PSD. It can cause jagged image.
 - 3) It rarely happens.
-

❖ Basic Function of Cassette Lock Motor

- The purpose of cassette lock motor is to firmly hold the cassette not to move during scanning.
- Bi directional of C-lock lever depending on the cassette size
- It can recognize which direction a C-lock lever moves through a proximity sensor.
- Cassette lock motor L & R are connected to a RFID board.



❖ Common Issue with Cassette Lock Motor

Knocking noise in the end of erasing process

- 1) Cassette lock motor is not released because a set screw for C lock lever is a little bit loosen.
- 2) New cassette lock motor that improves the way of C-lock lever assembly has been released.
- 3) If old version of cassette lock motor is installed, recommend replacing new version of cassette lock motor.

Cassette lock motor working is not stopped


- 1) You can hear non-stopped cassette lock motor working noise when either the cassette is inserted or scanning is in the end of process.
 - 2) In this case, proximity sensor is damaged, so that scanner does not detect the position of C-lock lever.
 - 3) Need to replace either faulty cassette lock motor.
-

❖ Cassette Lock Motor Revision History

Cassette Lock Motor version	Released date	Improvement	Compatibility
	2016.Mar.02	Change C lock lever locking way	Compatible with FireCR flash AA to AC


❖ Basic Function of RFID Board (1)

- The main purpose of RFID board is to recognize Cassette info and Speed plate info through RFID communication.



❖ Basic Function of RFID Board (2)

- RFID (Radio-Frequency Identification) is the technology to identify product through radio frequency.
- RFID system consists of RFID chip and RFID reader. RFID chip (Antenna and Tag) is attached on Cassette housing and Speed plate. RFID board (RFID reader) can identify information that saved in the RFID tag.
- Advantage of RFID Communication
 - 1) Contactless method (they need to be close.)
 - 2) RFID communication is reliable and fast
 - 3) RFID has a permanent long life span if there is no physical damage.



❖ Common Issue with RFID Board

Scanner can not read the IP


- 1) Either RFID chip broken or RFID board malfunctioning can cause IP recognition issue.
- 2) If it has an issue with all the cassettes, there is more possibility to be caused by a RFID board.
If it has an issue with a specific cassette, there is more possibility be caused by a cassette housing.

❖ RFID Board Revision History

RFID board version	Released date	Improvement	Compatibility
V1.2		Initial board	Compatible with FireCR flash AA to AB
V1.4	2015.Jul.7	Antenna matching for liable RFID recognition	Compatible with FireCR flash AC
V1.5	2016.Apr.11	Circuit change to minimize electrostatic effect.	Compatible with FireCR flash AC

❖ Basic Function of Home Sensor and Limit Sensor

- The purpose of home sensor and limit sensor are to stop a stage at home position and limit position.
- Home sensor and Limit sensor are all micro switches.
- Home position and Ready to Scan position are different




❖ The Common Issue with Home Sensor

Knocking noise when turning on the scanner power.

- 1) Stage moves to home position when turning on the power.
- 2) If home sensor is broken, step motor keeps working in order for stage to move backward to reach home position, so it leads to knocking noise. In this case, a home sensor needs to be replaced.

❖ Basic Function of MP Detector

- The purpose of MP detector is to detect the IP inside the scanner.
- MP detector is photo type sensor.
- The function of MP detector can be disabled in the FireCRF.ini.



❖ The Common Issue with MP Detector Sensor

Moving plate time out error


1) If MP detector detects an imaging plate within predefined time from scanning start, moving plate time out error happens.

2) There are several reason that can delay scanning.

- Step motor shaft and ShaftBackHolder brass gear are worn off, and then it can cause delaying scanning.
 - Tiny contact between CassetteTopPlate and IP can cause this issue.
 - Step motor drive belt is worn out.
 - As temporary workaround, MP can be disabled in the FireCRF.ini file.
-

❖ Basic Function of Cassette Micro Switch

- The purpose of both cassette micro switches is to detect cassette when it is inserted in the scanner.
- When it is detected, the cassette lock motor is engaging.



❖ The Common Issue with Cassette Micro Switch

Cassette lock motors are not engaging from time to time

1) Both cassette lock motors are not engaging even though cassette is inserted. Put up or move right or left the cassette, and they suddenly work because Micro switches are insensitive.



❖ Basic Function of ShaftHolderBack and Step Motor

- A step motor and a ShaftHolderBack work with a step motor drive belt to be allowed for stage to move back an forth.

Step Motor Drive Belt


Step Motor

ShaftHolderBack




❖ Basic Function of ShaftHolderBack and Step Motor (2)

- A stepper motor is used to achieve precise positioning via digital control.



A stepper motor rotates with a fixed step angle, just like the second hand of a clock. This angle is called "basic step angle".



The amount the stepper motor rotates is proportional to the number of pulse signals (pulse number) given to the driver. The relationship of the stepper motor's rotation (rotation angle of the motor output shaft) and pulse number is expressed as follows:

❖ The Common Issue with ShaftHolderBack

Knocking noise has appeared when turning on the scanner power.

- 1) The stage moves to the home position when turning on the scanner power.
 - 2) The stage stops moving when home sensor is manually detected.
 - 3) The stage does not move in the guide of ShaftFrontHolder assembly because the shaftHolderBack's brass gear is worn out, and then it can not overcome the friction in the guide of ShaftFrontHolder Assembly.
-

❖ The Common Issue with Step motor

Stage movement malfunctioning in the middle of scan.

1) Step motor shaft was fallen out in the middle of scan.

❖ The Common Issue with Step motor drive belt

Knocking noise


- 1) Step motor drive belt is worn out.

❖ Upgrade Kit

- Why implemented AC Wall mount kit_1

1) Some of our distributors reported that IP was not completely fitted in the cassette housing from time to time.

2) It turned out that both cassette housing lock bearing were partially pushed at initial position when wallmounted, so that either IP was still remained in the scanner or IP was not fitted in the housing when cassette was removed.




❖ Upgrade Kit

- AC Wall mount kit_1


1) AC wall mount kit_1 consists of a cassette top plate and a mold adaptor.

2) The purpose of AC wall mount kit_1 is to completely fit the IP in the housing when wallmounted.




❖ Upgrade Kit

- With AC Wall mount kit_1
- 1) No contact between cassette lock bearing and CassetteTopPlate at home position.



❖ Understanding FireCR Flash; Auto Alignment

- The purpose of Auto Alignment is to bring the red laser back to the best beam position to acquire better image quality.
- Best beam position is one of our system parameter. It is saved in the factory.
- Auto alignment function is performed either just before scanning or during calibration.



❖ Understanding FireCR Flash; Precondition for Scanning

Cassette recognition

Scanner read the cassette itself and cassette size.

Calibration file

Calibration file need to be in the Quantor+ folder.


Auto align

Red laser need to hit both PSDs.

Three preconditions are satisfied.
It can scan the cassette.

❖ Understanding FireCR Flash; Calibration

- Every scanner has a different “**Fiber Bundle Condition**”.
Fiber bundle collectors have different light sensitivity.



Fiber Bundle

Less sensitive

Less sensitive

13	14	13	17	18	15	14	13
13	14	13	17	18	15	14	13
13	14	13	17	18	15	14	13
13	14	13	17	18	15	14	13
13	14	13	17	18	15	14	13
13	14	13	17	18	15	14	13
13	14	13	17	18	15	14	13
13	14	13	17	18	15	14	13



More sensitive, Vertical band



18	18	18	18	18	18	18	18
18	18	18	18	18	18	18	18
18	18	18	18	18	18	18	18
18	18	18	18	18	18	18	18
18	18	18	18	18	18	18	18
18	18	18	18	18	18	18	18
18	18	18	18	18	18	18	18
18	18	18	18	18	18	18	18


Uniform brightness

❖ Understanding FireCR Flash; Calibration




❖ Understanding FireCR Flash; Calibration

Note: X-ray exposure must cover entire cassette



❖ Understanding FireCR Flash; Calibration

- Menu/Device Calibration



❖ Understanding FireCR Flash; Calibration

▪ Calibration Procedure

Device Calibration 00 %

The X-ray beam should cover the entire 35x43 IP area.

Reader Position
 Table Top Wall Mount

Show Calibration Data Intensity Value

Auto Alignment Erase Calibration

ScanBlank ScanLowDose ScanMidDose ScanHighDose

541	2003	10335	34221
(500~700)	(2000~4000)	(9000~13000)	(33000~37000)
0.00kVp	0.00kVp	0.00kVp	0.00kVp
0.00mAs	0.00mAs	0.00mAs	0.00mAs
SID 0 mm	SID 0 mm	SID 0 mm	SID 0 mm

ScannerReady None 100um

Button4 Cancel

Step 1: Select Reader Position

Step 2: Auto alignment

Step 3: Erase

Run an erase cycle to remove any residual radiation that may be left on the phosphor.

Step 4: Scan Blank

Without exposing the cassette, insert it into the reader and press the “Scan Blank” button. **Note: Use the same cassette for the entire calibration.**

Step 5, 6, & 7: Scan Low, Medium, & High Dose

Expose the entire cassette at the recommended values and if the value is out of range adjust mAs until the numbers are green. Step 7: Calibration! Press and wait until the software confirms that the calibration was successful.

Note: Cancelling the calibration before completion will force you to start over.

❖ Understanding FireCR Flash; Calibration

Understanding the Cal-files:


- Calibration files can be found in the software folder. Windows Photo Viewer can view the Cal-files. We recommend that you open the “High Dose” calibration of each cassette size to verify an artifact free calibration.

3543 Cassette Calibration	
File	Description
Calf0.tif	ScanBlank
Calf1.tif	ScanLowDose
Calf2.tif	ScanMidDose
Calf3.tif	ScanHighDose
Sectionf.dat	TableTop Calibration file
Sectionfw.dat	Wallmount Calibration file

* Need to confirm Artifact free through Calf3.tif

❖ Understanding FireCR Flash; Image Quality Setup

- Basic understanding Image quality setup
 - 1) The basic concept of the image quality setup is to bring the red laser near to fiber bundle.
 - 2) Uniform image brightness.




❖ Understanding FireCR Flash; Image Quality Setup

- Image quality setup order

1) Align Calibrator


The purpose of the align calibrator is to optimize the slow speed value for bringing out the best aligner motor performance for fine tuning the best beam position.



In case of low SlowSpeed value

Aligner motor force is too low, and the it is approaching the saved best beam position, but it is not within range.


❖ Understanding FireCR Flash; Image Quality Setup



In case of high SlowSpeed value

The aligner motor force is way too strong, it overshoots the best beam position.


❖ Understanding FireCR Flash; Image Quality Setup



In case of optimal SlowSpeed value


❖ Understanding FireCR Flash; Image Quality Setup

- Image quality setup order
- ### 2) PSD Calibrator



change actual reading range into ideal reading range through scale change.

After PSD calibrator



❖ Understanding FireCR Flash; Image Quality Setup

- Image quality setup order

3) Best Beam Find

The purpose of the best beam find process is to find the best red laser position to show the best image quality.

Software calculates the best PSD position to meet following two condition simultaneously.

- Red laser is as near as possible to the fiber bundle.
- Uniform image brightness


Best Beam Find in order

- Cal0 Run
 - Find Best PSD
-

❖ Understanding FireCR Flash; Image Quality Setup

Cal0 Run

1) Align motor stability test




2) Rough PSD position calculation

3) Automatic ADC offset value calculation.


❖ Understanding FireCR Flash; Image Quality Setup

Find Best PSD

1) Fiber bundle bending test



Bad fiber bundle
shape



Good fiber bundle
shape


2) Align motor stability test

3) Fine PSD position calculation

4) Automatic PMT gain value calculation


❖ Understanding FireCR Flash; Image Quality Setup

Risk-based PSD position adjustments




Box color	Intensity Value	Risk	Risk ratio(%)
Red	Very high	Very high	150
Yellow	High	High	125
Light Green	Normal	Normal	100
Dark Green	Low	Low	70

Default :
Normal(+800)



❖ Understanding FireCR Flash; Scanner Control

- Menu/Scanner Control



❖ Scanner Control

Scanner Information

Readonly parameters		Editable parameters	
Model	FireCR Flash / Flash30	Resolution	100
H/W	1.0.0.1	PMT Gain	86
B/L	1.0.1.165	ADC Offset	-30
APP	1.0.1.165	DHCP	No
PN	FR41-00EFAC-106291	IP address	192.168.1.36
MAC	8C:4B:59:41:02:B3	Subnet Mask	255.255.255.0
Mode	USB / ScannerReady	Gate Way	192.168.1.1
Calibration	Table	LSavedPSD	-3000
IP		RSavedPSD	-2500
RPM	1800.51	<input type="checkbox"/> Save PSD Location	
LPSD	+2836 / +0.17311	<input type="checkbox"/> Edit parameters	
RPSD	-5086 / -0.31044	Save Params Auto Align Stop Align	
LPeak/RPeak	691903 / 691898	<input type="checkbox"/> keyboard mode	
Temperature(L/E)	32.7 / 22.5	length	150 power
RFID	0		6000
Gain(R)	86	L +	R +
State	Idle	L -	R -

Inspection Reset Scanner RPM Monitor

Stage

speed High length 580000 Forward Stop Backward Ready Pos

auto align

End 4000 Left -1100 fine stop Period 20 waitM 210 waitP 12

Best Beam Right -1100 coarse Gap 200 SlowSpeed 64

Erase On Erase Off Laser On Laser Off

Align Calibrator

60 Start Stop

PSD Calibrator LPSD Sample RPSD Sample

Aligner aging test


0x71 1 SetRegister 0x71 GetRegister

- APP: Firmware version
- BL: BootLoader version
- PN: Serial number
- Resolution: HD or SD
- LsavedPSD: Optimized LPSD setting value
- RsavedPSD: Optimized RPSD setting value
They are saved through Best Beam Find process.
- LPSD: Actual LPSD value
- RPDS: Actual RPSD value
- RFID: Cassette housing RFID info
- IP: Cassette size
- RPM: The rotation speed of square mirror
- Forward: Stage manually move forward.
- Backward: Stage manually moves backward.
- Ready Pos: Stage moves to ready position

❖ Scanner Control


- PMT gain

PMT gain value is adjusted by applied voltage



❖ Scanner Control

- ADC Offset



❖ Factory Software, SDKContainer

Splash Preprocessor for 3DISC v 1.0.1.165

Generate DQE | Raw Image | Geo Image | Monitor | Fin Image | mark ROI | Clear ROI

5876x 300y 0m 0v l +0 r +0 AVG 0 STD 0.0 SNR 0.0

Scale x1

Connect Scanner

Browse Last Image

192.168.1.205

Connect with IP

Scan Stop

normal scan

scanner Resolution

100um 200um

Align before Scan

Disable

Enable

Profile

Manual Erase

VSNR Filter

Anisotropic Filter

Start Cycle

Stop Cycle

Open Image | Save Image

Process | Auto Contrast

Calibration | Back to Original

SysInfo | Scanner Control

DCM automation

Low 0 < >

Mid 32767 < >

Hi 65535 < >

Flash30 None

skip check section.dat Table Top

use calibration data FMC Edge

Stripe Remover 0 2

MaxSpeed 1 3

Salt Noise Filter

front align motorversion
35x43 Calibrated
24x30 Calibrated

Strip removal filter
We can turn on/off this filter in the FireCRF.ini.

Full speed (Speed plate 70)

Dot artifact removal filter

Vertical line removal filter
We can turn on/off it in the FireCRF.ini

Grid suppression filter
We can turn on/off it in the FireCRF.ini

❖ Factory Software, SDKContainer

Splash Preprocessor for 3DISC v 1.0.1.165

Generate DQE

Open Image Save Image

Process Auto Contrast

Calibration Back to Original

SysInfo Scanner Control

DCM automation

Low 0 < >

Mid 32767 < >

Hi 65535 < >

Flash30 None

skip check section.dat

use calibration data

Stripe Remover

MaxSpeed

Salt Noise Filter

Table Top
FNC_edge
 0 1 2

1 3

front align motorversion
35x43 Calibrated
24x30 Calibrated

Raw Image Geo Image Monitor Fin Image mark ROI Clear ROI

2008x 2252y 0m 0v l +0 r +0 AVG 0 STD 0.0 SNR 0.0

ScannerInfoForm

Signature	SoF
Position	0x300000
StructSize	348
MAC_ADDR	8C:4B:59:00:00:00
Vendor	3DISC
Model	FireCR Flash
PN	FR.11-00CH00-100200
HardWareVersion	1.0.0.1
BootLoaderVersion	1.0.0.60
ApplicationVersion	1.0.0.90
Name	No name
saveToSD	0
saveSysInfoToSD	0
ipAddr	192.168.1.209
netmask	255.255.255.0
gateway	192.168.1.1

load

from file

from Scanner

save

to file

to Scanner

UDI

SystemInfo

bootloader
solution
FPGA
SystemInfo

Manually load Sysinfo file.

Refresh Sysinfo parameters.

Save Sysinfo parameters as file.

Save Sysinfo parameters after changing some of Sysinfo parameters.


Create UDI

Manually upload each item.

❖ Factory Software, SDKContainer

- Tag

Tag contains very important information related with PSD reading



❖ Factory Software, SDKContainer

X count **Y count** **Mirror number** **Intensity** **PSD L position** **PSD R position**

Raw Image Geo Image Monitor Fin Image mark ROI Clear ROI

0x 1541y 1m 1541v l +3023 r +5127 - AVG 14280 STD 0.0 SNR 0.0 Scale x3