


Model

FireCR Flash AA FireCR Flash AB FireCR Flash AC FireCR Flash AD / FireCR Spark

• The Description of the Problem

White images

Fishbone Diagram



Check the PMT gain and ADC offset in the scanner

If PMT gain value is corrupt or 0, it can't amplify electric signal. It could cause the white images.

If PMT gain is corrupt or 0, please send an email to service1@digiray.co.kr

Readonly parameters Editable parameters			
Model	FireCR Flash / Flash30	Resolution	100
H/W	1.0.0.1	PMT Gain	81
B/L	1.0.1.165	ADC Offset	0
APP	1.0.1.165	DHCP	No
PN	FR41-00DEAC-100200	IP address	192.168.1.36
MAC	8C:4B:59:41:02:B3	Subnet Mask	255.255.255.0
Mode	USB / WarmUp	Gate Way	192.168.1.1
Calibration	Table	LSavedPSD	7084
IP		RSavedPSD	7164
RPM	0.00	Save PSD Location	
LPSD	-4/-0.00024	Edit parameters	
RPSD	+0 / +0.00000	Save Params	Auto Align Stop Align
LPeak/RPeak	691882 / x	keyboard mode	
Temperature(L/E)	27.6 / 22.1	length 150 power 6000	
RFID	0		
Gain(R)	81	L +	R +
State	Idle		
Inspection Res	et Scanner RPM Monitor	L-	R -
Stage speed High V length 580000 Forward Stop Backward Ready Pos			
auto align End 4000 Left -1100 fine Period 20 waitM 210 waitP 12 Best Beam Right -1100 coarse stop Gap 200 SlowSpeed 90			
Erase On Erase Off Laser On Laser Off 60 Start Stop			
PSD Calibrator LPSD Sample RPSD Sample Aligner aging test			
0x71 1 SetRegister 0x 71 GetRegister			


DIGIRAY

Measure the High voltage generator voltage

Measure the voltage DC on the driver board during scanning only for FireCR Flash

Measured voltage can be varied depending on the PMT gain value.


• Threshold: -350 < Measured voltage <-550



Measure the voltage DC on the photo module board during scanning only for FireCR Spark.


Measured voltage can be varied depending on the PMT gain value.

• Threshold: -350 < Measured voltage <550



PMT assembly

Please refer to the FireCR Flash/Spark service manual for PMT replacement.



DIGIRAY